



Matrix and Concourse Tiles require no permanent bonding they are designed to be loose laid. They require butting tightly in all directions. Leave no more than a 3 mm gap around the perimeter of the matwell as the modules do not expand.

The layout for the modules is as follows:

1. Find the centre line of the matwell from left to right. The centre line should run through the centre of the module (should you find a small gap on 1 side of the matwell when all modules have been placed move the module from the centre line so that you are only cutting 1 side of the modules to 1 edge of the matwell).
2. Modules are laid in landscape format the first module should be placed at the door threshold in the matwell.
3. Place each module to the left and right of this module leaving NO gaps until the edge is reached.
4. Lift the edge of the module and coat the matwell frame with chalk.
5. Gently lay the module over the matwell edge to coat the module with the chalk and cut on the inside of the chalk line using a sharp fixed blade knife.
6. Repeat the operations 3 - 5 placing modules from the first line of modules to the back of the matwell until the matwell is fully covered with the modules and the installation is complete.

The Matrix Tile has a carpet pile direction.

Please ensure the modules are installed with the carpet pile running in the same direction to obtain the maximum visual effect.

Modules need to be turned 180 degrees if there is a colour variation of the carpet when placed in situ.

Matrix Tile and Concourse modules are butt fitted and require no clearance as they are manufactured to be stable in a normal temperature changing environment. There is no detrimental effect to the performance of the Matrix Tile and Concourse modules effectiveness on which way the modules are installed. It is purely a visual effect and is determined by the customers personal choice.